



CÓD.	REF.	INK-JET COLOR	COLOR
90158	0318C001	PIXMA MG5750 / 6850 / 7750	●
153674	0331C001	PIXMA TS5051 / 5053 / 5055 / 6050 / 6051 / 6052 / 8051 / 8052 / 9050 / 9055	●
152579	0331C004	PIXMA MG6852 / TS6050 / TS8050 (ALTA CAPACIDAD)	●
152011	0332C001	PIXMA MG6852 / TS6050 / TS8050	●
152012	0333C001	PIXMA MG6852 / TS6050 / TS8050	●
152010	0334C001	PIXMA MG6852 / TS6050 / TS8050	●
152578	0385C001	PIXMA MG6852 / TS6050 / TS8050	●
155156	0386C007	571 PIXMA MG5750 / MG6850 / MG7750	●●●●
37851	0615B001	PIXMA MP150/170/450, PIXMA iP1300/1700, PIXMA MP160/180/460, PIXMA MP220/210, PIXMA iP2500/1800, PIXMA MP190/140 PIXMA iP2600/1900, PIXMA MX310/300, JX210P/510P, PIXMA iP2200, JX200/500, PIXMA iP1200/1600	●
37853	0616B001	PIXMA MP160/180/460, PIXMA MX310/300, JX210P/510P • PIXMA iP2200 • JX200/500	●
37852	0617B001	PIXMA MP150/170/450, PIXMA iP1300/1700, PIXMA MP160/180/460, PIXMA MP220/210, PIXMA iP2500/1800, PIXMA MP190/140, PIXMA iP2600/1900, PIXMA MX310/300	●●●
37854	0618B001	PIXMA MP150/170/450, PIXMA iP1300/1700, PIXMA MX310/300	●●●
37855	0619B001	PIXMA iP6220D/6210D	●●●
37863	0620B001	PIXMA MP500/800, PIXMA iP4300/5300, PIXMA MP830/530/800R, PIXMA MP600/810, PIXMA MP600R//610, PIXMA MX850, PIXMA iP4500, PIXMA iP670D, PIXMA MP970, PIXMA PRO9000 PRO9000 MARKLL	●
37860	0621B001	PIXMA MP500/800, PIXMA iP4300/5300, PIXMA MP830/530/800R, PIXMA MP600/810, PIXMA MP600R//610, PIXMA MX850, PIXMA iP4500, PIXMA iP670D, PIXMA MP970, PIXMA PRO9000, PRO9000 MARKLL, PIXMA MP510, PIXMA MP520, PIXMA iP3500, PIXMA MX700, PIXMA iX5000/4000, PIXMA iP4200/5200/5200R, PIXMA iP6600D	●
90158	0318C001	PIXMA MG5750 / 6850 / 7750	●
153674	0331C001	PIXMA TS5051 / 5053 / 5055 / 6050 / 6051 / 6052 / 8051 / 8052 / 9050 / 9055	●
152579	0331C004	PIXMA MG6852 / TS6050 / TS8050 (ALTA CAPACIDAD)	●
152011	0332C001	PIXMA MG6852 / TS6050 / TS8050	●
152012	0333C001	PIXMA MG6852 / TS6050 / TS8050	●
152010	0334C001	PIXMA MG6852 / TS6050 / TS8050	●
152578	0385C001	PIXMA MG6852 / TS6050 / TS8050	●
155156	0386C007	571 PIXMA MG5750 / MG6850 / MG7750	●●●●
37851	0615B001	PIXMA MP150/170/450, PIXMA iP1300/1700, PIXMA MP160/180/460, PIXMA MP220/210, PIXMA iP2500/1800, PIXMA MP190/140 PIXMA iP2600/1900, PIXMA MX310/300, JX210P/510P, PIXMA iP2200, JX200/500, PIXMA iP1200/1600	●
37853	0616B001	PIXMA MP160/180/460, PIXMA MX310/300, JX210P/510P • PIXMA iP2200 • JX200/500	●
37852	0617B001	PIXMA MP150/170/450, PIXMA iP1300/1700, PIXMA MP160/180/460, PIXMA MP220/210, PIXMA iP2500/1800, PIXMA MP190/140, PIXMA iP2600/1900, PIXMA MX310/300	●●●
37854	0618B001	PIXMA MP150/170/450, PIXMA iP1300/1700, PIXMA MX310/300	●●●
37855	0619B001	PIXMA iP6220D/6210D	●●●
37863	0620B001	PIXMA MP500/800, PIXMA iP4300/5300, PIXMA MP830/530/800R, PIXMA MP600/810, PIXMA MP600R//610, PIXMA MX850, PIXMA iP4500, PIXMA iP670D, PIXMA MP970, PIXMA PRO9000 PRO9000 MARKLL	●
37860	0621B001	PIXMA MP500/800, PIXMA iP4300/5300, PIXMA MP830/530/800R, PIXMA MP600/810, PIXMA MP600R//610, PIXMA MX850, PIXMA iP4500, PIXMA iP670D, PIXMA MP970, PIXMA PRO9000, PRO9000 MARKLL, PIXMA MP510, PIXMA MP520, PIXMA iP3500, PIXMA MX700, PIXMA iX5000/4000, PIXMA iP4200/5200/5200R, PIXMA iP6600D	●
37861	0622B001	PIXMA MP500/800, PIXMA iP4300/5300, PIXMA MP830/530/800R, PIXMA MP600/810, PIXMA MP600R//610, PIXMA MX850, PIXMA iP4500, PIXMA iP670D, PIXMA MP970, PIXMA PRO9000, PRO9000 MARKLL, PIXMA MP510, PIXMA MP520, PIXMA iP3500, PIXMA MX700, PIXMA iX5000/4000, PIXMA iP4200/5200/5200R, PIXMA iP6600D	●
37862	0623B001	PIXMA MP500/800, PIXMA iP4300/5300, PIXMA MP830/530/800R, PIXMA MP600/810, PIXMA MP600R//610, PIXMA MX850, PIXMA iP4500, PIXMA iP670D, PIXMA MP970, PIXMA PRO9000, PRO9000 MARKLL, PIXMA MP510, PIXMA MP520, PIXMA iP3500, PIXMA MX700, PIXMA iX5000/4000, PIXMA iP4200/5200/5200R, PIXMA iP6600D	●
37871	0624B001	PIXMA iP670D, PIXMA MP970, PIXMA PRO9000 PRO9000 MARKLL, PIXMA iP6600D	●
37872	0625B001	PIXMA iP670D, PIXMA MP970, PIXMA PRO9000 PRO9000 MARKLL, PIXMA iP6600D	●
37858	0628B001	PIXMA iP4200/5200/5200R	●
52223	0894B001AA	LP 17/24/ IPF 500/600/700/710/610/605/720	●
51700	0895B001AA	LP 17/24/ IPF 500/600/700/710/610/605/720	●
51701	0896B001AA	LP 17/24/ IPF 500/600/700/710/610/605/720	●
51702	0897B001AA	LP 17/24/ IPF 500/600/700/710/610/605/720	●
51703	0898B001AA	LP 17/24/ IPF 500/600/700/710/610/605/720	●
46922	1509B001	PIXMA iP100	●
46921	1511B001	PIXMA mini260, PIXMA iP100	●●●
152585	1998C005	PIXMA PARA TS6150 / TS8150 / TR7550 / TR8550 MULTIPACK	●●●●

● = INKJET

