

CÓD.	REF.	Nº PÁG.	LÁSER COLOR	COLOR
38452	0263B002	2000	FAX L 100/120 , ISENSYS FAX L 100/120/140/160/MF 4010/4120/4140/4150/4270/4320D/4330D/4340D/4350D/4370DN/4380DN/4660PL/4690PL , PC D 440/450	●
38444	0266B002	2500	iSENSYS LBP 3300/3360 , LBP 3300	●
43953	0917B002	6000	LBP3200/3300/3360	●
38445	0985B001AA	6000	iSENSYS LBP 3460 , LBP 3460	●
47297	1153B002	4500	FAX L 3000/3000IP , I-SENSYS FAX L 3000/3000 IP , LASER CLASS 810/830 I	●
31960	1491A003BA	3000	FC 100/108/120/125/200/200S/204/204S/206/208/210/220/220S/224/224S/226/228/230/300/310/330/330L / 336/350/500/530/700/740/750/760/770/780 , PC 300/310/320/325/330/400/420/425/430/530/550/700/710/720/740/750/760/770/780/790/795/800/850/860/890/920/921/950/140/150/160/170/745	●
31959	1550A003	2500	LBP 1110/1120/200/200V/250/350/380/00/810	●
97797	1557A003BA	2700	FAX L 200/220/240/250/260/260I/280/290/295/300/350; LASER CLASS L 300/LC4000/LC4500/LC6000	●
46926	1660B002	6000	iSENSYS LBP 5300/5360 , iSENSYS LBP MF , 8450/9130/9170/9220Cdn/9280Cdn	●
46916	1870B002	1500	iSENSYS LBP 3010/3100	●
46917	1871B002	2000	iSENSYS LBP 3250	●
75157	1980B002	2300	LBP5050/5050N/MF8030CN	●
75158	1979B002	1500	LBP5050/5050N/MF8030CN	●
75159	1978B002	1500	LBP5050/5050N/MF8030CN	●
75160	1977B002	1500	LBP5050/5050N/MF8030CN	●
155108	2199C002	3100	052H I-SENSYS LBP212 / LBP214 / LBP215 / MF421 / MF426 / MF429	●
74417	2659B002	2900	LBP7200CDN/MF8300/LBP7660CDN/MF8340/MF8580CDW/LBP7210CDN	●
57373	2642B002	5000	LBP7750	●
57374	2641B002	5000	LBP7750	●
74415	2661B002	2900	LBP7200CDN/MF8300/LBP7660CDN/MF8340/MF8580CDW/LBP7210CDN	●
74416	2660B002	2900	LBP7200CDN/MF8300/LBP7660CDN/MF8340/MF8580CDW/LBP7210CDN	●
57372	2643B002	5000	LBP7750	●
79652	2662B002	3400	LBP-7200CDN/ MF8330CDN/ MF8350CDN/ M8380CDW/ MF8360CDN/ MF 8340CDN/ , LBP-7680CX/ LBP-7660CDN/MF8300/ LBP-7210CDN/ MF8540CDN/ MF8550CDN/ MF8580CDW/ MF729CX/ MF728CDW/ MF724CDW	●
57181	3479B002	2100	iSENSYS LBP 6300DN/6650DN/6310DN/6670DN/6680X , iSENSYS MF 5840DN/5880DN/5940DN/5980DN/6140DN/6180DW , LBP 6670DN/6680X/7680CX	●
57182	3480B002	6400	iSENSYS LBP 6300DN/6650DN/6310DN/6670DN/6680X , iSENSYS MF 5840DN/5880DN/5940DN/5980DN/6140DN/6180DW , LBP 6670DN/6680X/7680CX	●
154820	3483B002	1200	I-SENSYS LBP6200D / LBP6230DW	●
74366	3484B002	1600	LBP6000 LBP6000B LBP6020 LBP6020B 1600	●
90741	3500B002	2100	I-SENSYS MF4410 / 4450D / 4580DN / L150	●
154564	4367B002	1000	729 Y I-SENSYS LBP7010C / LBP7018C	●
154562	4368B002	1000	729 M I-SENSYS LBP7010C / LBP7018C	●
154563	4369B002	1000	729 C I-SENSYS LBP7010C / LBP7018C	●
154561	4370B002	1200	729 BK I-SENSYS LBP7010C / LBP7018C	●
90725	6269B002	1500	731 LBP7100CN / LBP7100CW	●
155157	6270B002	1500	731 M I-SENSYS LBP7100CN / LBP7110CW / MF623CN / MF628CW / MF8230CN / MF8280CW	●
90726	6271B002	1500	731 LBP7100CN / LBP7100CW	●
154829	6272B002	1400	731 BK I-SENSYS LBP7100CN / LBP7110CW / MF623CN / MF628CW / MF8230CN / MF8280CW	●
155158	6273B002	2400	731 BK I-SENSYS LBP7100CN / LBP7110CW / MF623CN / MF628CW / MF8230CN / MF8280CW	●
38443	7616A005	2000	iSENSYS LBP2900/3000/2900B · LBP 290/3000	●
38446	7833A002	3500	Fax L380/380S/390/400 , i-SENSYS Fax L380S , PC D300/320/340	●
93903	8489A002	2500	IMAGECLASS MF 5500 , iSENSYS LBP 200 iSENSYS MF 3220/3240 , LBP 300LDA/300LDF/300N/3200	●
39368	9424A004	2500	iSENSYS LBP 5000/5100/5000	●
79752	9435B002	2400	CANON I-SENSYS MF211/212W/216N/217W/226DN/ , CANON I-SENSYS MFW 229D , CANON I-SENSYS LBP151DW	●
156557	3009C002	3100	057 I-SENSYS LBP223DW / 226DW / 228D / MF443DW / 445DW / 446W	●

