



CÓD.	REF.	Nº.	Nº PAG.	INK-JET COLOR	COLOR
49796	C13T07114H16	T0711H	385	STYLUS D120/DX74X0/DX84X0/DX9400F/SX205/SX215/SX218/SX405/SX415/SX515W/SX600FW/SX610FW STYLUS OFFICE/B40W/B1100/BX300F/BX310FN/BX600FW/BX610FW	●
37572	C13T07124012	T0712	485	STYLUS D78/D92/D120/DX40X0/DX44X0/DX50X0/DX60X0/DX7000F/DX74X0/84X0 / DX9400F/S20/S21/ SX105/SX115/SX205/SX215/SX218/SX405/SX415/SX515W / X600FW/SX610FW/ STYLUS OFFICE/B40W/ BX300F/BX310FN/BX600FW/BX610FW	●
37569	C13T07134012	T0713	485	STYLUS D78/D92/D120/DX40X0/DX44X0/DX50X0/DX60X0/DX7000F/DX74X0/84X0 / DX9400F/S20/S21/ SX105/SX115/SX205/SX215/SX218/SX405/SX415/SX515W / X600FW/SX610FW/ STYLUS OFFICE/B40W/ BX300F/BX310FN/BX600FW/BX610FW	●
37571	C13T07144012	T0714	485	STYLUS D78/D92/D120/DX40X0/DX44X0/DX50X0/DX60X0/DX7000F/DX74X0/84X0 / DX9400F/S20/S21/ SX105/SX115/SX205/SX215/SX218/SX405/SX415/SX515W / X600FW/SX610FW/ STYLUS OFFICE/B40W/ BX300F/BX310FN/BX600FW/BX610FW	●
42921	C13T07154012	T0715	250/350	STYLUS D78/D92/D120/DX40X0/DX44X0/DX50X0/DX60X0/DX7000F/DX74X0/DX84X0/DX9400F/S20/S21/ SX105/SX115/SX205/SX215/SX218/SX405/SX415/SX515W/SX600FW/SX610FW/ STYLUS OFFICE/B40W/ BX300F / BX310FN/BX600FW/BX610FW	●●●●
57643	C13T07914010	T07914	450	STYLUS PHOTO 1400/1500W/P50/PX650/PX700W/PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD	●
57645	C13T07934010	T07934	745		●
57646	C13T07944010	T07944	690		●
57644	C13T07924010	T07924	1530		●
57647	C13T07954010	T07954	560		●
57648	C13T07964010	T07964	1110		●
38116	C13T08014011	T0801	300		STYLUS PHOTO P50/PX650/PX660/PX700W/ PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD/R265/R285/R360/RX560/RX585/RX685
38154	C13T08024011	T0802	900	STYLUS PHOTO P50/PX650/PX660/PX700W/ PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD/R265/R285/R360/RX560/RX585/RX685	●
38189	C13T08034011	T0803	440	STYLUS PHOTO P50/PX650/PX660/PX700W/ PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD/R265/R285/R360/RX560/RX585/RX685	●
38239	C13T08044011	T0804	660	STYLUS PHOTO P50/PX650/PX660/PX700W/ PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD/R265/R285/R360/RX560/RX585/RX685	●
38249	C13T08054011	T0805	410	STYLUS PHOTO P50/PX650/PX660/PX700W/ PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD/R265/R285/R360/RX560/RX585/RX685	●
38250	C13T08064011	T0806	590	STYLUS PHOTO P50/PX650/PX660/PX700W/ PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD/R265/R285/R360/RX560/RX585/RX685	●
90935	C13T08074011	T0807	220	EPSON STYLUS PHOTO P50/PX650/PX660/PX700W/PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD/R265/R285/R360/RX560/RX585/RX685	●●●●
46002	C13T0807401	T0807	300/300	STYLUS PHOTO P50/PX650/PX660/PX700W/ PX710W/PX720WD/PX730WD/PX800FW/PX810FW/ PX820FWD/PX830FWD/R265/R285/R360/RX560/RX585/RX685	●●●●●
45931	C13T0891401	T0891	180	STYLUS S20/S21/SX105/SX115/SX205/SX215/ SX218/SX405/SX415 • STYLUS OFFICE BX300F	●
45932	C13T0892401	T0892	185	STYLUS S20/S21/SX105/SX115/SX205/SX215/ SX218/SX405/SX415 • STYLUS OFFICE BX300F	●
45933	C13T0893401	T0893	185	STYLUS S20/S21/SX105/SX115/SX205/SX215/ SX218/SX405/SX415 • STYLUS OFFICE BX300F	●
45934	C13T0894401	T0894	185	STYLUS S20/S21/SX105/SX115/SX205/SX215/ SX218/SX405/SX415 • STYLUS OFFICE BX300F	●
90903	C13T08954010	T0895	170	STYLUS S20 / 21 / SX105	●●●●
75126	C13T08954010	T0895	180/185/135/200	STYLUS S20/S21/SX105/SX115/SX205/SX215/ SX218/SX405/SX415 • STYLUS OFFICE BX300F	●
90930	C13T12814012	T1281	170	EPSON STYLUS OFFICE X305F / BX305FW / BX305FW EPSON STYLUS S22 / SX125 / SX130 / SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W	●
90929	C13T12824012	T1282	170	EPSON STYLUS OFFICE X305F / BX305FW / BX305FW EPSON STYLUS S22 / SX125 / SX130 / SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W	●
90928	C13T12834012	T1283	170	EPSON STYLUS OFFICE X305F / BX305FW / BX305FW EPSON STYLUS S22 / SX125 / SX130 / SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W	●
49788	C13T12844012	T1284	260	STYLUS S22 / SX125 / SX130 / SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / STYLUS OFFICE BX305 / F / FM	●
52941	C13T12854012	T1285	185/165	EXPRESSION HOME/XP-102/205/212/215/ 305/312/405/405WH/412	●●●●
49789	C13T12914012	T1291	380	STYLUS SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / SX525WD / SX535WD / SX620FW / STYLUS OFFICE B42WD / BX305F / 305FW / BX320FW / BX525WD / BX535WD / BX625FWD / BX630FW / BX635FWD / BX925FWD / BX935FWD	●
49790	C13T12924012	T1292	445	STYLUS SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / SX525WD / SX535WD / SX620FW / STYLUS OFFICE B42WD / BX305F / 305FW / BX320FW / BX525WD / BX535WD / BX625FWD / BX630FW / BX635FWD / BX925FWD / BX935FWD	●
49791	C13T12934012	T1293	445	STYLUS SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / SX525WD / SX535WD / SX620FW / STYLUS OFFICE B42WD / BX305F / 305FW / BX320FW / BX525WD / BX535WD / BX625FWD / BX630FW / BX635FWD / BX925FWD / BX935FWD	●
49792	C13T12944012	T1294	445	STYLUS SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / SX525WD / SX535WD / SX620FW / STYLUS OFFICE B42WD / BX305F / 305FW / BX320FW / BX525WD / BX535WD / BX625FWD / BX630FW / BX635FWD / BX925FWD / BX935FWD	●
90931	C13T12954012	T1295	380/445/ 330/545	STYLUS S22 / SX125 / SX130 / SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / STYLUS OFFICE BX305 / F / FM, EPSON STYLUS OFFICE BX305FW / EPSON WORKFORCE WF- 3010DW / WF-3530DTWF / WF-3540DTWF / WF-7015 / WF-7515 / WF-7525 / WF-3520DWF	●●●●
52943	C13T13014012	T1301	1000	STYLUS SX525WD / SX535WD/SX620FW/ STYLUS OFFICE , B42WD/ BX525WD/BX535WD/ BX625FWD/ BX630FW/ BX635FWD/ BX925FWD/BX935FWD/ WORKFORCE WF-3010DW/ WF-3520DWF/ WF7015/ WF7515/WF7525	●
49793	C13T13024012	T1302	765	STYLUS SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / SX525WD / SX535WD / SX620FW / STYLUS OFFICE B42WD / BX305F / 305FW / BX320FW / BX525WD / BX535WD / BX625FWD / BX630FW / BX635FWD / BX925FWD / BX935FWD	●
49794	C13T13034012	T1303	765	STYLUS SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / SX525WD / SX535WD / SX620FW / STYLUS OFFICE B42WD / BX305F / 305FW / BX320FW / BX525WD / BX535WD / BX625FWD / BX630FW / BX635FWD / BX925FWD / BX935FWD	●
49795	C13T13044012	T1304	765	STYLUS SX230 / SX235W / SX420W / SX425W / SX430W / SX435W / SX440W / SX445W / SX525WD / SX535WD / SX620FW / STYLUS OFFICE B42WD / BX305F / 305FW / BX320FW / BX525WD / BX535WD / BX625FWD / BX630FW / BX635FWD / BX925FWD / BX935FWD	●
52944	C13T13064012	T1306	765	STYLUS SX525WD / SX535WD/SX620FW/ STYLUS OFFICE , B42WD/ BX525WD/BX535WD/ BX625FWD/ BX630FW/ BX635FWD/ BX925FWD/BX935FWD/ WORKFORCE WF-3010DW/ WF-3520DWF/ WF7015/ WF7515/WF7525	●●●●
90758	C13T15904010	T1590	500	STYLUS PHOTO R2000	TRANSPARENTE

* = FOTO ●●●● = CLARO
● = INKJET

